Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONIKUMA CW905

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

ONIKUMA CW905 Gaming Mouse User Manual

Model: CW905 | Brand: ONIKUMA

1. Introduction

This user manual provides detailed instructions for the ONIKUMA CW905 Gaming Mouse. Please read this manual carefully before using the product to ensure proper operation and to maximize your gaming experience. This wired optical mouse features adjustable DPI settings and multi-color RGB lighting, designed for PC gamers.

2. Product Features

- **Adjustable DPI Settings:** Offers 6 customizable DPI levels (800/1600/2400/3200/4800/6400 DPI) for precise control and sensitivity adjustment, suitable for various gaming and creative tasks.
- **Multi-color RGB Lighting:** Features dynamic LED lighting effects to enhance your gaming environment. Easily switch lighting effects and toggle lighting on/off.
- **7-Button Design:** Includes left button, right button, scroll wheel, DPI +/- buttons, and forward/backward buttons for versatile control.
- **Wide Compatibility:** Compatible with Windows 10, 8, 7, Vista, XP, and limited Mac OS support. Works with most major gaming PCs and laptops.
- **Durable Construction:** Equipped with a 1.5-meter braided fiber cable and a high-quality USB interface for reliable and long-lasting performance.
- **Ergonomic Symmetric Design:** Engineered for comfortable hand-feeling and stress-free use, resistant to fingerprints, grease, and sweat.



Figure 1: Key features of the ONIKUMA CW905 Gaming Mouse, including its RGB lighting, DPI levels, button count, and ergonomic design.

3. Specifications

Feature	Detail
Model	ONIKUMA CW905
Color	Black
Type	USB Wired Optical Mouse

Adjustable DPI	800/1600/2400/3200/4800/6400 DPI
Number of Buttons	7
Backlight	RGB Backlight
Interface	USB
Operating Voltage	5V
Cable Length	1.5 meters
Mouse Dimensions	125 x 76 x 41 mm
Mouse Weight	131 grams
Compatibility	Windows 7/8/10/XP, Vista & Mac OS

4. Package Contents

- 1 x ONIKUMA CW905 Gaming Mouse
- 1 x User Manual

5. Setup Guide

Follow these steps to set up your ONIKUMA CW905 Gaming Mouse:

1. **Unpack the Mouse:** Carefully remove the ONIKUMA CW905 Gaming Mouse and its accessories from the packaging.
2. **Connect to Computer:** Locate an available USB port on your computer (PC or Laptop). Insert the USB connector of the mouse into the USB port.
3. **Driver Installation:** The mouse is plug-and-play. Your operating system (Windows, Mac OS) should automatically detect and install the necessary drivers. This process may take a few moments.
4. **Verify Functionality:** Once the drivers are installed, the mouse's RGB lighting should illuminate, and you should be able to move the cursor on your screen.



Figure 2: The ONIKUMA CW905 Gaming Mouse, ready for connection.

6. Operating Instructions

6.1 Button Functions

The ONIKUMA CW905 Gaming Mouse features 7 programmable buttons:

- **Left Button:** Standard left-click function.
- **Right Button:** Standard right-click function.
- **Scroll Wheel / Middle Button:** Scrolls content up/down; press for middle-click function.
- **DPI+ Button:** Increases DPI sensitivity.
- **DPI- Button:** Decreases DPI sensitivity.

- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Backward Button:** Navigates backward in web browsers or file explorers.



Figure 3: Button layout and functions of the ONIKUMA CW905 Gaming Mouse.

6.2 DPI Adjustment

The mouse offers 6 adjustable DPI levels, indicated by different LED colors:

- 800 DPI: Green
- 1600 DPI: Pink
- 2400 DPI: Blue
- 3200 DPI: Red
- 4800 DPI: Cyan

- 6400 DPI: Yellow

To change the DPI setting, press the **DPI+** button to increase sensitivity or the **DPI-** button to decrease sensitivity. The LED color will change to indicate the current DPI level.



Figure 4: Visual representation of DPI levels and their associated LED colors.



Figure 5: The adjustable DPI range of the ONIKUMA CW905 Gaming Mouse.

6.3 RGB Lighting Control

The ONIKUMA CW905 features multiple RGB lighting effects:

- **To change lighting effect:** Press and hold the **Left Button**, then simultaneously press the **DPI-** button. Repeat to cycle through different lighting effects.
- **To turn lighting on/off:** Press and hold the **Scroll Wheel / Middle Button**, then simultaneously press the **DPI+** button. Repeat to toggle the lighting on or off.



Figure 6: The ONIKUMA CW905 Gaming Mouse showcasing its precise tracking and RGB lighting.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your gaming mouse:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Sensor Care:** Keep the optical sensor on the bottom of the mouse clean and free from dust or debris. Use a cotton swab or compressed air if necessary.
- **Cable Management:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.

- **Storage:** When not in use, store the mouse in a clean, dry place away from direct sunlight and extreme temperatures.




Figure 7: The ergonomic and durable design of the mouse, which is resistant to common wear factors.

8. Troubleshooting

If you encounter issues with your ONIKUMA CW905 Gaming Mouse, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Mouse not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cable is securely plugged in. Try a different USB port. Restart your computer. Check Device Manager for driver issues.
Cursor movement is erratic or jumpy	Dirty optical sensor, unsuitable mouse pad surface.	Clean the optical sensor on the bottom of the mouse. Use a clean, non-reflective mouse pad.
RGB lighting not working	Lighting turned off, software conflict.	Try toggling the lighting on/off using the **Scroll Wheel / Middle Button** + **DPI+** combination. Ensure no conflicting software is running.
Buttons not functioning	Software conflict, physical damage.	Restart your computer. Test the mouse on another computer. If the issue persists, contact customer support.

9. Warranty and Support

The ONIKUMA CW905 Gaming Mouse comes with a comprehensive warranty and support:

- **30-Day Money-Back Guarantee:** If you are not satisfied with your purchase, you may return the product within 30 days for a full refund.
- **12-Month Worry-Free Warranty:** The product is covered by a 12-month warranty against manufacturing defects. This warranty does not cover damage caused by misuse, accident, modification, or unauthorized repair.
- **Customer Support:** For technical assistance, warranty claims, or any other inquiries, please contact ONIKUMA customer support through the retailer's platform or the official ONIKUMA website.

© 2024 ONIKUMA. All rights reserved.
This manual is subject to change without notice.

Related documents

CW905